

Description	Range	Method
Screw torque driver	0 - 20 N.m.	ISO 6789-2003
Torque wrench meter	0 - 1,500 N.m.	ISO 6789-2003
Air torque driver	0 - 50 N.m.	ISO 6789-2003
Air torque wrench	0 - 50 N.m.	ISO 6789-2003
Setting torque wrench	0 - 1,500 N.m.	ISO 6789-2003
Torque gauge	0 - 20 N.m.	ISO 6789-2003
Torque calibrator	0 - 1,500 N.m.	ASTM D 3474, BS 7882:1997
Digital torque tester	0 - 20 N.m.	ASTM D 3474, BS 7882:1998
Force gauge (Digital/Analog)	1 mg - 100 kg	Comparison with standard weight
Tension gauge (Digital/Analog)	1 mg - 100 kg	Comparison with standard weight
Hardness tester	0 - 100 Scale	JIS K 6301, JIS S 6050, ASTM D2240
Durometer / Rubber hardness	0 - 100 Scale	JIS K 6301, JIS S 6050, ASTM D2240
Push - Pull scale	1 mg - 100 kg	Comparison with standard weight
Tensile tester	0 - 5,000 kg	ISO 7500-1
Universal testing machine	0 - 5,000 kg	ISO 7500-1